

VK-4C

Kitchen scale calibration

(For 4keys)

PARAMETER SETTING

Press “ZERO” key and turn on the scale, window shows a group of number (Offset Values).

Auto Power off : press “TARE” key to enter auto power off setting, it displays A---0.

Press “ZERO” key can select in turn: A---0, A---1, A---5, A---10

A---0: no auto power off A---1: 1 minute auto power off

A---5: 5 minutes auto power off A---10: 10 minutes auto power off

Capacity Setting: press “zero” key to enter capacity setting

Press “TARE” key to choose capacity

CALIBRATION SETTING:

1. Turn on the scale, in the normal weighing status
2. Press **【ZERO】** and **【TARE】** KEY out 5 seconds, it displays inner code.
3. Press **【ZERO】** one time, scale display CALL→[xxxx], xxxx is full capacity.
4. Put the weight on the scale according to scale display value. Scale automatic calibration, When the calibration is finished, the scale back to normal weighing.